





Isopropyl Alcohol Sanitizer (P305)

ISOPROPYL ALCOHOL SANITIZER - With a 90% purity, this product can be used as a cleaner, degreaser or either solvent. The isopropyl alcohol is colorless and clear, does not contain colorants or odors and is friendly to use. It cleans and removes all types of dirt deeply, halos and fingerprints from any surface, evaporating quickly and without leaving any residues. It can be used for the cleaning of domestic environments, brushes, cell phones or smartphones, mousepads, keyboards, monitors, computers and laptops, electronic devices such as CD / DVDs, magnetic tapes, printed circuit boards. Also useful for cleaning optical devices such as lenses, photo lens/gear and microscopes.



Specifiche Tecniche:

Quantity	400 ml
Packaging Box	12 Pz.
Aspect	Cylinder can containing under pressure fluid
Color	Transparent
Odour	Alcohol
Relative density	at 20°C 0,65 ÷ 0,69 g/ml
Flash point	Under 0° C extremely flammable
Pressure at 20°C	5/7 bar
Initial boiling point	82 °C (liquid based)
Boiling interval	82°C - 85°C (liquid based)
Flash point	10 °C (liquid based)

HOW TO USE:

- 1. Spray the product directly on the surface or spray on a cloth to then apply.
- 2. Wipe the surface with a clean cloth.
- 3. Repeat the cleaning process if necessary.
- 4. Wait for the complete evaporation of the solvent.

It's advisable to test the surface to be treated in a hidden place before using it.

MODALITY OF STORAGE

Before using: stock the product in a dry location and don't stock it with a temperature under 0°C and over 45°C, after the use, keep containers closed. In the original package, the product can be conserved for 24 months (warranty). The product doesn't expire.

After the first usage: conserve in a fresh and dry location, away from hot spring. Keep out of reach of children.

This information, even if reliable, must be considered only approximate. We are not responsible for the wrong use of the product, or the violation of any license. Before using, the users should verify the suitability of the product for its specific use.

BEFORE USE, CONSULT THE SAFETY DATA SHEET OF THE PRODUCT



Ambro-Sol - Via per Pavone del Mella, 21 - 25020 - Cigole (BS) Italy - www.ambro-sol.com - info@ambro-sol.com