



## High Pressure Blow (P303)

This spray acts efficiently on parts that are difficult to clean, such as corners or narrow splits. A small spray/air pressure removes dust and filth. It's also perfect for cleaning keyboards, glasses, computer monitors and cameras.



**HIGH PRESSURE BLOW** – It removes dust from hard to reach places. It is a must for cleaning lenses, camera lens, computers and any kind of mechanism.

### Technical Specifications:

Barcode	EAN: 8034108890326
Quantity	400 ml
Box / Case	12 Pz.
Aspect	Tin-Plate can containing under pressure fluid
Color	n.s.
Odour	Odourless
Relative density	at 20°C 0,52 ÷ 0,56 g/ml
Flash point	Und. 0° C extremely flammable
Pressure at 20°C	4/6 bar
Boiling range	-161,5 °C – 0,5 °C
Auto-ignition time	287°C +- 537°C
Solubility	24,4-60,4 mg/l
Partition coefficient	1,09 +- 2,8 (n-octanol / H2O )

**HOW TO USE:** Hold the bottle upright and spray the surface or the specific area to be treated. Use the straw supplied to blow parts difficult to reach. Use in small intervals, avoid long sprays as it can effect air flow." Do not spray on over-heated or tensioned electrical equipment. The product is extremely flammable. Attention: using the can upside down, can generate a cooling effect down to -50 ° C.



**EROGATORE SOFFIO ALTA PRESSIONE**  
HIGH PRESSURE BLOW ACTUATOR



### MODALITY OF STORAGE

Before using: stock the product in a dry location and don't stock it with a temperature under 0°C and over 35°C, after the use, keep containers closed. In the original package, the product can be conserved for 24 months (warranty). The product doesn't expire.

After the first usage: conserve in a fresh and dry location, away from hot spring. Keep out of reach of children.

This information, even if reliable, must be considered only approximate. We are not responsible for the wrong use of the product, or the violation of any license. Before using, the users should verify the suitability of the product for its specific use.

**BEFORE USE, CONSULT THE SAFETY DATA SHEET OF THE PRODUCT**